

# TOP 5!

## Quick Tips to use walers for achieving straight, sharp walls.

1.

**Use enough brackets.** Place waler brackets at every joint in your wall. Fillers under 5 inches do not require an additional bracket.

2.

**Lock in your splice board.** When splicing waler boards together mid-wall, place a third board, the splice board, on top. The splice board should be long enough to reach two brackets on either side of the splice.

3.

**Keep your corners sharp.** Waler to the outside of your 90° corners. Be sure to place a bracket at the corner to keep it sharp.

4.

**Don't think of walers as scaffolds.** Walers are NOT scaffolds! Remember walers are not designed or intended as a safe working platform.

5.

**Look for T-walls.** Always waler opposite T-walls. You need to catch at least two panel joints on either side of the T.

Western Forms offers additional services to help you get the most out of your investment, whether it's on-the-job performance or on-the-market resale value. Contact your local representative to learn more about Technical Support, Release Agents, Form Repair Services, and Buying & Selling Used Forms.





**Western  
Forms**

**PROTECT YOUR  
INVESTMENT!**

## **Prepare your waler brackets for top performance:**

### WALER TIME SAVERS

- Paint your waler brackets bright orange or yellow so they don't get lost in the dirt
- Keep standard and PinLock™ walers in separate buckets to save time and reduce errors
- Train all crew members on proper usage, placement, and removal techniques
- Good waler practices minimize the need for extra bracing